

SHARP

Wireless Adapter

for Sharp PN-LBxx3

Setup Guide

Supplied Components

If any components are missing, please contact your dealer.

- ☐ Wireless adapter: 1
- ☐ Wireless adaptor anti-theft fitting: 1
- ☐ Wireless adapter anti-theft fitting screw (M3 x 6): 2

Attaching the wireless adapter

1. Connect the supplied wireless adapter to the left-side USB port (📶) for HOME mode.
2. Attach the included wireless adapter anti-theft fitting using the wireless adapter anti-theft fitting screw (M3 x 6) (supplied) (x2).

